


CC300 CC500 CC700 Command Connector



Document

Document Details

Version

V1.1 20250206

(V1.0 published 20240805)

Firmware

Firmware version can be verified on Verkada

Command command.verkada.com.

Product Models

This install guide pertains to models CC300-HW, CC500-HW, and CC700-HW.

© Copyright 2025 Verkada Inc. All rights reserved.

Verkada and the Verkada logo are registered trademarks or service marks of Verkada Inc. (“Verkada”). All other trademarks are the property of their respective owners.


Verkada may make changes to this document at any time without notice. The information presented herein may be inaccurate or outdated, and Verkada is under no obligation to maintain it. ALL INFORMATION IS PROVIDED “AS-IS” AND WITHOUT ANY WARRANTIES, IMPLIED, EXPRESS, OR OTHERWISE. VERKADA DISCLAIMS LIABILITY FOR ALL DAMAGES, INCLUDING WITHOUT LIMITATION ANY DIRECT, INDIRECT, SPECIAL, INCIDENTAL, PUNITIVE, OR CONSEQUENTIAL DAMAGES, ARISING OUT OF USE OF THIS DOCUMENT.

Any intellectual property rights relating to Verkada products are and shall remain Verkada’s exclusive property. Use of any Verkada product is subject to Verkada’s end user agreement or other executed agreement with Verkada. No license, either expressed or implied, to use or distribute any Verkada product is granted under this document.

This document may not be sold, resold, licensed or sublicensed and may not be transferred without Verkada’s prior written consent. No part of this document may be reproduced in whole or in part without the express written consent of Verkada.




What's in the box



Command Connector



60cm Mount Rails (2 pcs)
(80cm ordered separately)



M5x6mm Rack Mount Screws
(8 pcs - attached to
Mount Rails)



M4x6mm Flat Head Screws
(4 pcs)



M5x15mm Truss Head Screws
(2 pcs)



Front Cover



Power Cord
(North America only)



M5x10mm Truss Head Screws
(6 pcs)

What you'll need

- A smartphone or laptop
- A #2 Phillips screwdriver or low power drill with a #2 Phillips driver bit
- A flat head screwdriver or low power drill with a flat head driver bit
- An ethernet cable

Placement

Server rack with 1U space available.

Connect




For easy registration and setup, scan the QR code on the product.

If you prefer to manually register your product, please proceed to:

verkada.com/start



Overview




Installation

Server Rack Post Mounting Guidance

Note: Mount Rack Post Style

Use the following hardware if installing mount rails on a M5 threaded server rack post:



M5x6mm Rack Mount Screws
(8 pcs - attached to
Mount Rails)




Use the following hardware if installing mount rails on a non-threaded server rack post:



M5x15mm Truss Head Screws
(2 pcs)



M5x10mm Truss Head Screws
(6 pcs)



Note: Two Post Server Rack

If installing on a 2 post server rack, Verkada recommends using a 2 post rack rail kit or a server rack shelf to support the Command Connector unit.

Please contact Verkada.com/support for additional mount recommendations..




Installation

Outer Mount Rail (1/2)


Remove the inner mount rail from the outer mount rail.



Loosen screws highlighted in the image.
Do not remove them completely.



Remove the front and rear screws.




Installation




Outer Mount Rail (2/2)

Extend the outer outer mount rail to match the depth between the server rack posts.

Insert and tighten the front and rear screws. See the *Server Rack Post Mounting Guidance* section for mounting screw guidance.




Tighten the screws highlighted in the image. Repeat the steps above to install the outer mount rail on the opposing side.




Installation

Front Cover Removal

Slide the release switch to the left to disengage the front cover mount pins from the right rack ear.




Swing the right side of the front cover away from the Connector to disengage the front cover mount pins from the left rack ear and set aside.




Installation

Inner Mount Rail


To install the inner mount rail to the Connector, align the holes on the inner rail with the posts on the side of the Connector.



Slide the inner mount rail away from the front of the device to engage the posts.




Insert and tighten the M4X6mm flat head screw to secure inner mount rail positioning. Repeat the above steps to install the inner mount rail on the opposing side.



Installation

Connector Mounting

Align the inner mount rails on both sides of the Connector with the outer mount rails installed on the server rack and insert the Connector by sliding inward.



The Connector installation on the server rack is complete.




Installation

Front Cover Install


Align pins on the left side of the front cover with the holes on the left rack ear and insert.



Slide the release switch to the left to depress the mount pins on the right side of the front cover.




Swing the right side of the front cover so the mount pins on the right side align with the holes on the right rack ear. Release the switch to secure the front cover.




Installation

HDD Replacement (1/4)


Push the button to the right of the blue stripe to release the HDD caddy door.



Gently remove the HDD caddy from the central unit.




Flip over the HDD caddy.




Installation

HDD Replacement (2/4)


Locate the green release lever and push down, rotating 90 degrees counterclockwise, to disengage the lock mechanism. Then, flip the caddy back over.



Slide the HDD towards the front of the caddy by gently pushing on the back side of the HDD.




To remove the HDD, lift it straight upwards out of the caddy and set aside.




Installation

HDD Replacement (3/4)


Insert replacement HDD by aligning HDD with the caddy rails. Gently slide in from the back side until it clicks into place.



Rotate the green lever down until it clicks into place to secure the HDD in the caddy.




Insert the caddy into the HDD slot on the central unit.




Installation

HDD Replacement (4/4)

Gently push the caddy into the main device until it is secure.



Rotate the front door back into its original position until it clicks into place.



Appendix

Compliance

Caution	<ol style="list-style-type: none">1. Maintenance and repair work must always be carried out by qualified technical personnel. Disconnect power from the unit when performing a maintenance task.2. Wiring methods used for the connection of the equipment to earth shall be in accordance with the National Electrical Code, ANSI/NFPA 70, and the Canadian Electrical Code, Part 1, CSA C22.1.3. Equipment shall be connected to a grounded (earthed) outlet when using a grounded power cord. The grounding pin shall not be removed from the power cord.4. Replacement of the battery with an incorrect type may risk fire or explosion5. Please contact certified dealers for power adapters and batteries.
FCC Compliance	<p>This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense</p>



Appendix
Support

Thank you for purchasing this Verkada product. If for any reason you're experiencing issues or need assistance, please contact our 24/7 Technical Support Team immediately.

Sincerely,
The Verkada Team
verkada.com/support

