

ARM Cortex-M tracing with Orbcode





## ARM tracing components




Figure C1-1 Relationship between ITM and other debug components



#### Documents

- ARMv7-M Architecture Reference Manual
  - Description of tracing components
- ETM Architecture Specification
  - Description of ETM component
- Cortex-Mx Technical Reference Manual
  - Cortex-M limitations
- MCU documentation (Reference Manual, Datasheet)
  - Vendor specific limitations (what is implemented what is not)
  - How to enable GPIO setup, clocks
- + others referenced documents



# Trace Port Interface Unit (TPIU)

- Output trace data outside of MCU
- Output protocols
  - Serial Wire Output, UART
  - Serial Wire Output, Manchester
  - Parallel Trace, Clock + N (1-4) bits
- Output formats
  - Raw ITM (SWO only, ETM discarded)
  - Formatted (ITM/ETM wrapped in TPIU packets)





## Trace Port Interface Unit (TPIU)


- TraceBusID differentiates trace sources
  - ITM\_TCR.TraceBusID ITM
    - Set to 1
  - ETM\_TRACEIDR ETM
    - Set to 2





## Instrumentation Trace Macrocell (ITM)


- Up to 8\*n (< 255) stimulus ports for user-defined data output
  - 32-bit wide
  - n implementation defined
- Synchronization packets
  - Configurable interval (with DWT registers)
- Timestamp
  - Retrieve MCU tick counter






# Data Watchpoint and Trace (DWT)

- PC sampling
- Exception entry/exit event
- Watchpoints implemented here






# Data Watchpoint and Trace (DWT)





### Embedded Trace Macrocell (ETM)

- The Beast
- Trace every executed instruction
- Can stall CPU
- Triggering
- Check Cortex-M TRM details





### How to configure?

- Configure GPIO (per MCU docs)
- Configure TPIU/ITM/DWT/ETM (per ARM docs)
- Configure using:
  - Code (on startup, on command)
  - OpenOCD (TCL script)
  - GDB



#### Orbtrace

- Open (bitstream/schematics)
- FPGA-based
- Debug probe JTAG/SWD (CMSIS-DAP)
- Parallel trace receiver
- SWO receiver
- Fast!








### orbuculum

- Tools for handling ARM Trace output
  - Parallel trace from Orbtrace
  - SWO/UART trace from USB adapter
- Fan-out architecture
  - orbuculum receives trace output from hardware and exposes over TCP
  - orb\* tools receive stream form orbuculum and interpret it in various ways
  - Receive stream over network!







Verbosity = 2

orbuculum -v 2 -m 1000

Start concentrator

Report link usage every 1000ms

ITM TraceBusID = 1 (ITM)

obcat -t 1 -c 4,%c

Print data from ITM stimports

Print data from 4 ITM
Stimulus Port as characters

ITM TraceBusID = 1 (ITM)

orbtop -t 1 -e file.elf

Print PC sampling

ELF file (for functions/lines)