


ACC-MNT-ANGLE-1 Angle Mount



Document Details

Version

V1.2 20260112

(V1.0 published 20241004)

Firmware

Firmware version can be verified on Verkada
Command command.verkada.com.

Product Models

This install guide pertains to models
ACC-MNT-ANGLE-1

© Copyright 2024 Verkada Inc. All rights reserved.

Verkada and the Verkada logo are registered trademarks or service marks of Verkada Inc. ("Verkada"). All other trademarks are the property of their respective owners.


Verkada may make changes to this document at any time without notice. The information presented herein may be inaccurate or outdated, and Verkada is under no obligation to maintain it. ALL INFORMATION IS PROVIDED "AS-IS" AND WITHOUT ANY WARRANTIES, IMPLIED, EXPRESS, OR OTHERWISE. VERKADA DISCLAIMS LIABILITY FOR ALL DAMAGES, INCLUDING WITHOUT LIMITATION ANY DIRECT, INDIRECT, SPECIAL, INCIDENTAL, PUNITIVE, OR CONSEQUENTIAL DAMAGES, ARISING OUT OF USE OF THIS DOCUMENT.

Any intellectual property rights relating to Verkada products are and shall remain Verkada's exclusive property. Use of any Verkada product is subject to Verkada's end user agreement or other executed agreement with Verkada. No license, either expressed or implied, to use or distribute any Verkada product is granted under this document.


This document may not be sold, resold, licensed or sublicensed and may not be transferred without Verkada's prior written consent. No part of this document may be reproduced in whole or in part without the express written consent of Verkada.



What's in the box




Angle Mount




Mounting Ring



M4 Thumb Screws (2 pcs)
Length: 13mm Drive: T10 Security Torx



#8 Wall Screws (4 pcs)
Length: 1.5" Drive: #2 Phillips



#8 Wall Anchors (4 pcs)
Length: 1.5" Drill Size: 1/4"


What you'll need

- A compatible Verkada product with its hardware
- #2 Phillips screwdriver or power drill with a #2 Phillips driver bit
- 1/2" (12.7mm) drill bit, or larger, for routing cable through wall
- 1/4 inch (6.5mm) drill bit for wall anchors
- 1/8" (3mm) drill bit for pilot holes
- T10 Torx Security Screwdriver

Connect


For a list of compatible products, please visit:
<https://docs.verkada.com/docs/accessories-overview.pdf>

Overview



Angle Mount Hole Patterns

- A 4" Junction Box
- B Double Gang Junction Box
- C Single Gang Junction Box
- D 3.5" Junction Box
- E European Junction Box




Mounting Ring Hole Patterns

- A 4" Junction Box
- F CF83-E, CDX3-E, CDX3
- G CDX2-E, CF81-E
- H CDX2


Installation

Prepare the Camera


Use the provided T10 Torx Security Screwdriver to loosen the screws and lift the cover of the camera.



To remove the mount plate, loosen the mount plate screws with a T10 Torx Security Screwdriver and twist the camera counter clockwise. Lift the camera vertically off the mount plate and set aside.




Note: You will not use the camera mount plate when installing the camera onto the Angle Mount.



Wall Mounting

Drywall, plaster and wood paneling. For other surface materials, more specialized mounting hardware may be required.

Using the T10 Security Screwdriver, provided with the Verkada Camera, remove the mounting ring.




Mark the four pilot hole locations in the A-pattern, and drill 1/8" pilot holes.


After drilling, clear dust from holes.

Insert the wall anchors into the pilot holes until flush.

With a #2 Phillips head screwdriver, use the provided #8 Wall Screws to secure the Angle Mount to the wall.



Set the mounting ring back onto the Angle Mount and secure it by tightening the captive screws, using the T10 Security Screwdriver.



Installation

Mounting to a Verkada Camera

Retrieve the camera.




Refer to the *Preparation and Mounting* sections of the camera install guide for accurate cable installation.

Align the the camera's blue mounting slots with the thumb screws on the Angle Mount.

With thumbscrews fully inserted, rotate the camera clockwise.

Tighten the thumbscrews using the T10 Security Screwdriver.

Note: If mounting a CDX2, CDX2-E, CF81-E, use the thumbscrews from their respective mount plate, and the appropriate hole pattern, to secure the camera to the accessory.



Appendix

Support

Thank you for purchasing this Verkada product. If for any reason you're experiencing issues or need assistance, please contact our 24/7 Technical Support Team immediately.

Sincerely,
The Verkada Team
verkada.com/support

